MARK POSITION

MARK →



Press MARK to capture a position, press ENTER to confirm.

GO TO WAYPOINT

GOTO →

Press the GOTO key once & select waypoint name. Press ENTER to confirm the GOTO.

MOB FUNCTION

GOTO GOTO →



Press GOTO twice to activate man overboard function, press ENTER to confirm.

TRACBACK NAVIGATION

- *From map page, highlight CFG option & press ENTER.*
- *From track setup option, highlight TRACBACK, and press ENTER.*



GPS 12 KEYPAD USAGE

	Turns the unit on and off and activates screen backlighting.
PAGE	Scrolls through the main data pages in sequence and returns display from a submenu page to the main page.
MARK	Captures a position and displays the mark position page.
GOTO	Displays GOTO page with the waypoint highlighted for GOTO operation. Pressing GOTO twice activates MOB.
ENTER	Confirms data entry and activates highlighted fields to allow data entry.
QUIT	Returns display to a previous page, or restores a data field's previous value.
▲ ▼	Selects alphanumerical characters and menu choices and moves the field highlight from field to field.
◀ ▶	Moves the selected character field and moves the field highlight from field to field.

GARMIN®

1200 E. 151st Street Olathe, KS 66062
GARMIN (Europe) Ltd
Unit 5, The Quadrangle, Abbey Park Ind. Estate,
Romsey, U.K. SO51 9AQ

GPS 12 QUICK REFERENCE GUIDE

POWER ON SEQUENCE

Press the POWER key firmly to turn unit on. To power down, press and hold the POWER key for about 2 seconds.

Status Page will appear while the GPS 12 acquires satellites. To adjust the screen contrast, press the right arrow key. Use the arrow keypad to set the contrast, and press ENTER to confirm.



Once sufficient satellite signals have been acquired, the status page will be replaced by the Position Page.



© 1997 GARMIN Corporation
Printed in Taiwan Part #190-00143-01 Rev. A

OPERATION FLOWCHART

Main Page Sequence



To view a submenu page, highlight the menu listing and press ENTER.

To return to a previous menu page, press PAGE.